



MA-I84 CS4-圓管護木-長
CS4 FREE FLOATING
TUBULAR HANDGUARD (LONG VERSION)

- 01.CS4槍款，先將原護木都拆下只保留槍管
 - 02.依序放入，護木前段、波形彈簧、星狀環，使用星狀扳手鎖固槍管與槍身
 - 03.止付螺絲鎖緊護木前段與星狀環
 - 04.護木軌道先組裝(長軌道螺絲先不緊，可移動)
 - 05.護木組鎖至護木前段，長軌道(螺絲使用M4*P0.7*L10)對位後鎖緊，其餘螺絲對稱鎖緊
 - 06.先將防火帽取下，瓦斯鏡軌座放置於槍管
 - 07.確認瓦斯鏡軌座與槍身對垂直後，鎖於槍管下方溝槽
1. For CS4 series, take the original handguard out and only leave barrel.
2. Sequentially place forepart hand guard, wave springs, and delta ring. Use Allen key to tighten the barrel.
3. To secure and tighten the screws of forepart handguard and delta ring.
4. Install handguard tactical rail first (do not tighten the long tactical rail and make it moveable).
5. Lock the tactical rail on the forepart handguard, tighten the long rail with screw M4*P.07*L10 and the rest screws in the correct screw hole.
6. Take flash suppressor off and place gas rail base in the barrel.
7. Make sure the gas rail base is vertical with the barrel, then tighten it in the under notch of barrel.

